





DH 2-2M1, DH 2-2M2, DH 2-2MBTT2, DH 2-2MT1

Нажмите на для проверки наличия запчасти

Артикул	Наименование	Фото
74328	DH2 control panel панель управления	 A green printed circuit board (PCB) with two 7-segment displays at the top, each showing '8888'. There are various electronic components and connectors on the board.
74330	DH2 heating element элемент нагревательный	 A square orange heating element with a white electrical cord coiled on top. A small white label is attached to the cord.
74331	DH2 switch выключатель	 A black and red rocker switch with a red button and a black base. It has several electrical terminals on the back.
74329	DH2 timer таймер	 A black rectangular timer module with a digital display showing '8888' and a yellow arrow button on the right side.