


1. A (TOP COVER ASM)




PART LIST(TOP COVER ASM)

품번	부품명	PART NO.	수량	비고
A	TOP COVER ASM	110-395A/B	1	
A-1	TOP COVER	111-095A/B	1	
A-2	HINGE HOLDER	181-274A/B	1	
A-3	SCREW	0132410D	4	TTS2 4X10
A-4	HINGE HOLDER COVER	181-277A/B	1	
A-5	SCREW	328-007D	2	TAPPING SCREW 4X20 STS
A-6	HANDLE	113-101A/B	1	
A-7	SCREW	0132408D	2	TTS2 4X8
A-8	TOP COVER STICKER	381-506A	1	은무광 테트론지
A-9	SCREW	328-007B	2	TAPPING SCREW 4X13STS
A-10	TOP LOWER COVER	121-078A/B	1	
A-11	TOP LOWER COVER BEAM	174-016A	2	
A-12	TOP INSULATOR	271-018C	1	
A-13	CLAMP ASM	160-071A	1	
A-13-1	CLAMP KNOB	367-201B	1	
A-13-2	CLAMP SPRING	352-155A	1	
A-13-3	CLAMP BRACKET	193-055A	1	
A-13-4	CLAMP PIN	351-039E	1	
A-14	SCREW	0170424H	1	MTS 4X24,STS
A-15	TOP HEATER	212-067A	1	
A-16	TOP HEATER PLATE	146-077A	1	
A-17	COVER PACKING	331-060A	1	
A-18	T/HEATER PLATE BRACKET	354-006A	1	
A-19	SCREW	328-007B	9	TAPPING SCREW 4X13 STS
A-20	SCREW	328-007D	1	TAPPING SCREW 4X20 STS
A-21	EYELET	128-029A/B	1	
A-22	SEAL PACKING	332-133A/B	1	
A-23	EYELET PACKING	332-134A/B	1	

안전

5-2. A (BODY ASM, OVEN COVER ASM) PART LIST



PART LIST (BODY ASM 및 OVEN COVER ASM)

품번	부품명	PART NO.	수량	비고	
B-1	RUBBER PACKING	332-006A	1		
B-2	OVEN COVER	141-018A	1		
B-3	OVEN,5.4L(NEW),SR-3010	143-071B	1		
안전	B-4	MAGNET SWITCH ASM	222-002A	1	
안전	B-5	HEATING PLATE	210-076A	1	
B-6	SCREW	328-013A	5	TooTh SCREW PS 4x6	
B-7	SCREW	0132410D	3	TTS2 4X10	
안전	B-8	MICRO TEMP ASM	230-034W	1	
B-9	MICRO TEMP BRACKET	193-085A	1		
B-10	SCREW	0121410F	1	RTS1 4x10	
안전	B-11	SIDE HEATER	213-042G	1	
B-12	OVEN CASE	153-025M			
B-13	TAPPING SCREW	0143214H	5	CTS2 3X14	
안전	B-14	THERMOSTAT ASM	233-026B	1	
B-15	TAPPING SCREW	0132406D	1	TTS2 4X6	
B-16	HINGE PIN	351-094A	1		
B-17	RING CASE	123-043A/B	1		
B-18	SIDE INSULATOR	272-005E	1		
B-19	OUT CASE	131-115A/B	1		
B-20	CLAMP HOLDER	181-275A/B	1		
B-21	SCREW	0170436H	1	MTS 4X36	
B-22	SCREW	0132416C	2	TTS2 4X16 BLACK	
B-23	CLAMP HOLDER BRACKET	193-057A	1		
B-24	BASE COVER	127-008M/N	1		
B-25	SCREW	0131412H	4	TTS1 4X12 STS	
B-26	DEW DISH	371-041A	1		
B-27	D/DISH HOLDER BRACKET	193-102A	1		
B-28	DEW DISH HOLDER	181-276A/B	1		
B-29	SCREW	0132410H	2	TTS2 4X10 STS	
B-30	SCREW	0132416C	3	TTS2 4X16 BLACK	
안전	B-31	POWER CORD ASM	260-135B	1	
B-32	SCREW	0132414D	2	TTS2 4X14	
B-33	SCREW	311-005A	1	TAP TITE SCREW	
품번	부품명	PART NO.	수량	비고	

	B-34	LEG	377-013L/M	4	
	B-35	SCREW	0132410D	4	TTS2 4X10
안전	B-36	S/W LEVER GROSS ASM	190-098A/B	1	
	B-37	SWITCH LEVER ASM	190-099A	1	
	B-38	SWITCH KNOB	367-067M/N	1	
안전	B-39	MICRO SWITCH	227-013C	1	
	B-40	SWITCH LEVER	191-068A	1	
	B-41	SWITCH LEVER HOLDER	182-065A	1	
	B-42	SCREW	0131410D	2	TTS1 4X10
	B-43	PANEL	441-411A/B	1	
	B-44	SCREW	0110410F	1	PS 4x10
	B-45	LAMP HOLDER	171-065A/B	1	
	B-46	SCREW	0121306D	1	RTS1 3x6
	B-47	HOLE PACKING	332-100C/D	1	
안전	B-48	LAMP PWB ASM	240-112F	1	
	B-49	COOKING SILICONE PAD	332-090A	1	
	B-50	SHOVEL RICE	327-038A	1	
	B-51	CUP	361-036A	1	